
Instruction Manual

TU_US

DIGITAL ULTRASONIC THICKNESS GAUGE



Model: TU-US

Table of contents

1. Overview
- 1.1 Product specifications
- 1.2 Main functions
- 1.3 Measuring principle
- 1.4 Configuration
- 1.5 Operating conditions
2. Structure feature
- 2.1 Instrument appearance
- 2.2 Parts of the main body
- 2.3 Measurement screen
- 2.4 Keypad definition
3. Preparation
- 3.1 Transducer selection
- 3.2 Conditions and preparation of surfaces
4. Operation
- 4.1 Power on/ off
- 4.2 Transducer Set
- 4.3 Zero adjustment
- 4.4 Sound velocity calibration
- 4.5 How to perform measurements
- 4.6 Two- Point Calibration
- 4.7 Scan Mode
- 4.8 Limit set
- 4.9 Changing Resolution
- 4.10 Unit scale
- 4.11 Memory management
- 4.12 Data printing
- 4.13 System set
- 4.14 System information
- 4.15 EL Backlight
- 4.16 Battery information
- 4.17 Auto Power Off
- 4.18 System reset
- 4.19 Connection to PC
5. Menu operation
- 5.1 Enter the main menu
- 5.2 Enter the submenu
- 5.3 Change the parameter
- 5.4 Numeric digit input
- 5.5 Save and exit
- 5.6 Cancel and exit

6. Servicing
7. Transport and storage
- Appendix A Sound velocities
- Appendix B Application notes
8. Declaration of conformity

1. Overview

The Model TU-US is a digital ultrasonic thickness gauge. Based on the operating principles as SONAR, it is capable of measuring the thickness of various materials with an accuracy as high as 0.01 mm (or 0.001 inches). It is suitable for a variety of metallic and non-metallic materials.

1.1 Product Specifications

Display: 128 x 64 dot matrix LCD with EL backlight

Measuring range: 0.75 to 300mm (in steel)
- TU 80-0.01, TU 230-0.01 US, as well as TU 300-0.01 are measuring continuously with a resolution of 0.01

Sound velocity range: 1000 to 9999m/s

Resolution: 0.1/0.01mm (selectable)

Accuracy: \pm (0.5% thickness +0.04) mm, depending on material and conditions

Units: Metric/ Imperial units selectable

- Four measurements readings per second at single point measurement and ten per second at Scan Mode.
- Memory up to 20 files (up to 99 values for each file) of stored values

- Upper and lower limit can be preset. It will alarm automatically if the result value exceeds the limit.

- Case: Extruded aluminium body suitable for use under Poor working conditions

Power supply: 2x AA, 1.5V alkaline batteries
Typical operating time: about 100 hours (EL backlight off)

Transfer to PC: RS-232 serial port

Dimensions: 132 x 76.2 mm

Weight: 345g

1.2 Main functions

- Capable of performing measurements on a wide range of materials including metals, plastic,

Instruction Manual TU_US

- ceramics, epoxies, glass and other ultrasonic wave well- conductive materials.
- Four transducer models are available for special applications included coarse grain material and high temperature applications.
- Zero adjustment function
- Sound velocity calibration function
- Two- point calibration function
- Two measurement modes: Single point mode
Scan mode
- Coupling status indicator showing the coupling status
- Battery indication indicates the rest capacity of the battery
- "Auto sleep" and "Auto power off" function to conserve battery's life
- Optional software to transfer the memory data to PC
- Optional thermal mini- printer to print the measured data via RS-232 port.

	14	DataPro for Thickness Gauge	1	For use on the PC
	15	Communication Cable	1	

1.3 Measuring principle

The digital ultrasonic thickness gauge determines the thickness of a part or a structure by accurately measuring the time required for a short ultrasonic pulse generated by a transducer to travel through the thickness of the material, to reflect from the back or inside surface and be returned to the transducer. The measured two-way transit time is divided by two to account for the down-and-back travel path, and then multiplied by the velocity of sound in the material. The result is expressed in following relationship:

$$H = \frac{v \times t}{2}$$

Where: H ----> thickness of the test piece
 v ----> sound velocity in the material
 t ----> the measured round-trip transit time

1.4 Configuration

	No.	Item	Quantity	Note
Standard Configuration	1	Main body	1	
	2	Transducer	1	Model: N05/90°
	3	Couplant	1	
	4	Instrument Case	1	
	5	Operating Manual	1	
	6	Screwdriver	1	
	7	Alkaline battery	2	AA size
Optional Configuration	8			
	9	Transducer: N02		See Table3-1
	10	Transducer: N07		
	11	Transducer: HT5		
	12	Mini thermal printer	1	
	13	Print cable	1	

1.5 Operation conditions

Temperature: -20°C up to +60°C

Storage temperature: -30°C up to 70°C


Relative humidity: ≤ 90%

In the surrounding environment any kind of vibrations should be avoided, as well as magnetic fields, corrosive medium and heavy dust.


2. Structure feature

2.1 Instrument appearance

- 1 Main body
- 2 Transducer




2.2 Parts of the main body



- 1 Communication Socket
- 2 Aluminium case
- 3 Belt hole
- 4 Battery cover
- 5 Keypad
- 6 LCD Display
- 7 Socket of transducer (no polarity)
- 8 Control plate (inbuilt)
- 9 Aluminium case
- 10 Label

Instruction Manual TU_US

2.3 Measurement screen



Battery Information:

Displays the information of the rest capacity of battery

Coupling status:

Indicates the coupling status. While measurements are performed, this symbol should be on. If it isn't, the instrument is having difficulties in achieving a stable measurement and the thickness value displayed will most likely be erroneous.

Operating hint: Shows hints of current operation

FIL: File selection

MEM: Memory data viewing

PRB: Transducer set

VEL: Change velocity

CAL: Velocity calibration

DPC: Dual point calibration state

ZER: Probe zero state

SCA: Indicates that the current thickness measurement Mode is Scan mode, not Single point mode.

File name: current file name is shown

Record No./ Count: The current record number is indicated while this item is highlighted or the total record counts while it isn't highlighted.

Transducer Model: Current transducer model setting in the instrument










Sound velocity: Current sound velocity setting

Thickness reading: The present Single time measured value is displayed. ↑ means that the upper measuring limit is exceeded. ↓ means that the value is lower than bottom measuring limit.

Units label: If the **mm** symbol is on, the instrument is displaying the thickness value in millimetres and the sound velocity in **m/s**.

If the **in** symbol is on, the instrument is displaying the thickness value in inches and the sound velocity in **inch/us**.

2.4 Keypad definitions

	Turn the instrument on and off		Exit from current selection
	Turn on/off the EL backlight		Enter
	Probe Zero operation		Plus or scroll up
	Switch selection among items		Minus or scroll down
	Data Save or Data Delete		

3. Preparation

3.1 Transducer Selection

With this instrument it is possible to measure a wide range of different materials, started from various metals to glass and plastics. These different types of material require the usage of different transducers. Choosing the correct transducer is the most important thing to perform accurate and reliable measurements. Generally speaking, the best transducer for an operation is the one that sends sufficient ultrasonic energy into the material to be measured in the way that a strong, stable echo is to be received in the instrument. There are several factors that affect the strength of the traveling ultrasound. They are described as followed:

Initial signal strength: The stronger a signal is at the beginning, the stronger its echo will return. Initial signal strength is mainly a factor of the size of the ultrasound emitter in the transducer. A large emitting area will send more energy into the material being measured than a small one. Thus, a so-called "1/2 inch" transducer will emit a stronger signal than a "1/4 inch" transducer.

Absorption and scattering: As the ultrasound travels through a material, it is partly absorbed. If the material has got any grain structure, the sound waves will start scattering. Both of these effects reduce the strength of the waves and thus the instrument's ability to detect the returning echo. Ultrasound of higher frequency is absorbed and scattered more than ultrasound of lower frequency. While it may seem that using a lower frequency transducer is better in every instance, it should be mentioned that low frequencies are less directional than higher ones. Thus, a higher frequency transducer is a better choice for detecting the exact location of small pits or flaws in the material to be measured.

Geometry of the transducer:

The physical constraints of the environment sometimes determine a transducer's suitability for an operation. Some transducers are simply too large to be used in a confined area. If the available surface area for contacting with the transducer is limited, the usage of a transducer with a small surface is required.

Instruction Manual TU_US


Measurements on a curved surface, in example an engine cylinder wall, will require a transducer with an adapted surface.

Temperature of the material: If exceedingly hot surfaces are to be measured, high temperature transducers must be used. These transducers are built with special materials and techniques that allow them to withstand high temperatures without being damaged. Additionally, care must be taken if a "Zero adjustment" or a "Calibration to known thickness" is being performed with a high temperature transducer.

The selection of a proper transducer is often a matter of tradeoffs between various characteristics. Sometimes it is necessary to experience with a variety of transducers in order to find the one that works well for a special operation.

The transducer is the "business end" of the instrument. It transmits and receives ultrasonic sound waves which the instrument uses to calculate the thickness of the material being measured. The transducer is connected to the instrument via the attached cable and two coaxial connectors. The transducer has to be installed correctly to get reliable measurement results. Each plug must be fit into the adequate socket in the instrument.

Below there are shown two photos and a short description of the instruction use of a transducer.



The upper figure is a bottom view of a typical transducer. The two semicircles are visibly separated in the middle of the surface. One of the semicircles is conducting the echoed sound back into the transducer. When the transducer is placed against the material being measured, this is the area directly beneath the centre of the measured surface.

The below figure is a top view of a typical transducer. It is pressed against the top with the thumb or the index finger to hold the transducer in place. Only moderate pressure is sufficient to keep it stationary. Its surface must be placed flat against the surface of the material.

Table 3-1 Transducer selection

Model	Freq MHz	Dia metr mm	Measurement range	Lower limit	Description
N02	2	22	3.0mm~300.0mm(in steel) 40mm(grey Cast iron HT200)	20	For thick,highly attenuating or highly scattering materials
N05	5	10	1.2mm~230.0mm (in steel)	Φ20mm×3.0mm	normal measurement

N05	5	10	1.2mm~230.0mm(Stahl)	Φ20mm×3.0mm	normal measurement
N07	7	6	0.75mm~80.0mm (in steel)	Φ15mm×2.0mm	For thin pipe wall or small curvative pipe wall
HT5	5	14	3~200mm (Stahl)	30	For high temperature (lower than 300°C) measurement

3.2 Conditions and preparation of surfaces

At any kind of ultrasonic measurement, the shape and roughness of the surface being tested are of paramount importance. Rough and uneven surfaces may limit the penetration of the ultrasound through the material resulted by an unstable and therefore unreliable measurement.

The surface being measured should be clean and free of any small particulate matter, rust or scale. The transducer must be placed on a flat and even surface. To get it clean it might be helpful to use a wire brush or a scraper. In more extreme cases, rotary sanders or grinding wheels may be used. Care must be taken to prevent surface gouging which inhibits a proper transducer coupling.


Extremely rough surfaces such as the pebble-like finish of cast iron will be measured quite complicated. These kinds of surfaces comport to the sound beam like frosted glass on light: the beam becomes diffused and scattered in all directions.

In addition to this, rough surfaces account for an excessive wear of the transducer, especially when it is "scrubbed" along the surface. Transducers should be inspected time by time if there are any signs of abrasion.


If the transducer is worn off on one side more than on the other, the sound beam penetrating the test material may no longer be perpendicular to the surface of the material. In this case, it is difficult to exactly locate tiny irregularities in the material, as the focus of the sound beam no longer lies directly beneath the transducer.

4. Operation

4.1 Power on/ off

The instrument is turned on by pressing the  key.

If the instrument is initially turned on, the model type, the manufacturer information and the serial number will be displayed before entering the main measurement screen.

It is turned off by pressing the  key.





The instrument has got a special memory where all settings are stored even if it was powered off.

4.2 Transducer Set

The model of the transducer should be preset to the instrument before measurements are to be started. This


Instruction Manual TU_US

enables the user to select the transducer type among supported transducers according to frequency and diameter depending on application requirements. The following steps are to be used to select the applicable transducer model:


- 1) On the measurement screen, the  key has to be pressed multiple times to activate the [Transducer model] tab.
- 2) The  and the  key have to be pressed to switch to the desired transducer model.
- 3) The  key has to be pressed to exit.

The transducer model set can also be changed by menu operation. For this, please refer to chapter 5.

4.3 Zero adjustment

The  key is used to „zero“the instrument. It is just the same way as a mechanical micrometer is zeroed. If the instrument isn't zeroed correctly, all the measurements taken may be in error by an initially incorrect value. When the instrument is zeroed, this fixed error value is measured and automatically corrected for all subsequent measurements.


The instrument is "zeroed" as follows:

- 1) The instrument has to be powered on and the Two-point calibration function is OFF. The Zero adjustment is disabled in Two-point calibration mode.
- 2) The transducer had to be plugged in and it has to be made sure that the connectors are fully engaged. The surface of the transducer has to be checked: it has to be clean and free of any debris.
- 3) The model of the transducer set in the instrument has to be changed to the model currently used.
- 4) A single droplet of ultrasonic couplant is to be applied to the metallic control plate.
- 5) The transducer has to be pressed flat against the surface of the control plate.
- 6) While the transducer is firmly coupled to the control plate, the  key has to be pressed. The instrument will display "ZER" on the operating hint area while it is calculating its Zero point.
- 7) After "ZER" disappears, the transducer has to be removed from the control plate.

At this point, the instrument has successfully calculated its internal error factor and will compensate for this value in all following measurements.

When performing a "Zero adjustment", the instrument will always use the sound velocity value of the in-built control plate, even if any other velocity value has been entered for making actual measurements.

Though the last "Zero adjustment" will be stored it is generally recommended to perform a "Zero adjustment" whenever the instrument is turned on as well as, if a different transducer is used. This way it is ensured that the instrument has been zeroed correctly.

The  key has to be pressed and the Zero adjustment is terminated. The instrument returns to the measurement mode.





4.4 Sound velocity

In order to performing accurate measurements, the instrument must be set to the correct sound velocity of the material being measured. Different types of material have got different inherent sound velocities. If the instrument isn't set to the correct sound velocity, all the measurements will be deficient by some fixed percentage. The **One-point** calibration is the simplest and most commonly used calibration procedure, optimizing linearity over large ranges.

The **Two-point** calibration has got higher accuracy over small ranges by calculating the Zero adjustment and sound velocity.



Note: **One-** and **Two-point** calibrations should only be performed on material where the paint or the coating is removed; if not, it will result in a multi material velocity calculation which is surely deviating from the actual velocity of the material intended to be measured.

4.4.1 Calibration to a known thickness



- 1) A Zero adjustment has to be performed.
- 2) A couplant has to be applied to the sample piece.
- 3) The transducer has to be pressed against the sample piece, making sure that the transducer is placed flat on it. The display should show a thickness value and the coupling status indicator should appear.
- 4) As soon as a stable reading has been achieved, the transducer has to be removed. If the displayed thickness is different from the value shown while the transducer was coupled, step 3 has to be repeated.
- 5) The  and the  key has to be used to adjust the displayed thickness up or down until the thickness of the sample piece is matched.
- 6) The  key has to be pressed and the sound velocity value, which has been calculated before based on the thickness value that was entered, is displayed.
- 7) The  key has to be pressed to exit the calibration mode. Now, measurements can be performed.


4.4.2 Calibration to a known velocity

Note: This procedure requires that the sound velocity of the material being measured, is known. A table of the most common materials and their sound velocities can be found in Appendix A of this manual.


1. The  key has to be pressed multiple times to tab to the sound velocity item.
2. The  key has to be pressed to switch among the preset commonly used velocities. The preset sound




Instruction Manual TU_US



velocity value can be overwritten, if essential, up or down with the keys  and  until the sound velocity of the material to be measured is matched. This value may be above or below the preset sound velocity for a special material (see table in Appendix A).

3. The  key has to be pressed to exit from the calibration mode. The instrument is now ready to perform measurements.

Another method to set the instrument with a known sound velocity is as follows:

1) The submenu item **【 Test Set 】** → **【 Velocity Set 】** has to be highlighted and the  key has to be pressed to enter the sound velocity set screen.

2) The  key has to be pressed multiple times to tab to the numeric digit to be changed. The  /  keys have to be used to increase/ decrease numeric values on the display until the sound velocity of the material being measured is matched. An auto repeat function is built in, so that when the key is held down, numeric values will increment/ decrement at an increasing rate.

3) The  key has to be pressed to confirm or the  key has to be pressed to cancel the calibration.

To achieve the most accurate measurement results, it is generally advisable to calibrate the instrument to a sample piece of known thickness. The composition of materials (and thus, its sound velocity) sometimes varies from lot to lot and from manufacturer to manufacturer.

Calibration to a sample of known thickness ensures that the instrument is set as closely as possible to the sound velocity of the material being measured.

4.5 How to perform measurements

The instrument always stored the last measured value until a new measurement is made. In order for the transducer working in the right way there may not be any gaps between the contact area of the sensor and the surface of the material being measured. This is accomplished with the coupling fluid, commonly called "couplant". This fluid serves to "couple" or transfer the ultrasonic sound waves from the transducer, into the material and back again.

Therefore a small amount of couplant should be applied onto the surface of the material, before measurements are performed. Typically, a single droplet is sufficient.

After the couplant is applied, the transducer has to be pressed firmly against the area being measured. The coupling status indicator should appear on the display as well as a digit number. If the instrument has been "zeroed" properly and if it has been set to the correct sound velocity, the actual thickness of the material directly beneath the transducer will be indicated as a number in the display.

If the coupling status indicator doesn't appear or if it isn't stable or if the numbers on the display doesn't seem to be correct, it has to be checked whether there is an adequate

film of couplant beneath the transducer and whether the transducer is placed flat onto the material.

If conditions persist, sometimes it is necessary to select a different transducer (size or frequency) for the material intended to be measured.

While the transducer is in contact with the material, the instrument will perform four measurements every second, updating its display as it does so.

If the transducer is removed, the display will hold the last measurement performed.


Note: Occasionally a small film of couplant will be drawn out between the transducer and the surface, as the transducer is removed. If this happens, the instrument may perform a measurement through this couplant film, resulting in an erroneously measurement. This is comprehensible because one thickness value is observed while the transducer is in place and the other value is observed after the transducer is removed.


In addition, measurements performed through very thick paint or coatings may result in the paint or coating being measured rather than the material intended.

The responsibility for a proper use of the instrument, as well as the recognition of these types of phenomenon solely depend on the user of this instrument.

4.6 Two-point Calibration

Note: This procedure requires that the testing person has got two known thickness points on the test piece which are representative of the range being measured.



1) On the **【 Test Set 】** → **【 2-Point Cal 】** submenu item the  key has to be pressed to switch ON the Two-point mode. The exit from the menu to the measurement screen. The string "DPC" will appear on the operation hint area of the main measurement screen.


2) The  key has to be pressed to start the calibration procedure. The string "NO1" will appear on the operating hint area, indicating measuring the first point.

3) A small amount of couplant has to be applied to the sample piece.

4) The transducer has to be pressed against the sample piece at the first / second calibration point. It has to be made sure that the transducer is placed flat on the surface of the sample. Now the display should show any (probably incorrect) thickness value and the coupling status indicator should appear steadily.

5) As soon as a stable measurement is achieved, the transducer is to be removed. If the displayed thickness distinguishes from the value shown while the transducer was coupled, step 4 is to be repeated.

6) The  and the  key are to be used to adjust the material thickness up and down until it matches the material thickness of the sample piece.

7) The  key has to be pressed to confirm. The hint will change to "NO2" indicating to be ready to measure the second calibration point.


Instruction Manual TU_US

8) Steps 3 to 7 are to be repeated. The hint will change back to "DPC".
 The instrument is now ready to perform measurements within its range.

4.7 Scan mode

While the instrument excels in making single point measurements, it is sometimes necessary to examine a larger region, searching for the thinnest point. This instrument includes a feature, called SCAN- Mode, which allows to do just that.







During normal operation, it performs and displays four measurements every second which is adequate for single measurements. In SCAN- Mode, however, the instrument performs ten measurements every second and displays the readings while scanning. While the transducer is in contact with the material to be measured, it is always keeping track to finding the lowest measurements. The transducer may be "scrubbed" across the surface, any brief interruptions of the signal will be ignored. If it loses contact with the surface for more than two seconds, the instrument will display the smallest measurement it found.

On the [Test Set] → [Work mode] menu item the  key has to be pressed to toggle between single point mode and scan mode.

4.8 Limit set

With the Limit set feature the user is able to set an audible and visual parameter while taking measurements.


If a measurement is beyond the limit range, set by the user, the beeper will sound, if enabled. With this, the speed and efficiency of the inspection process is improved by elimination of constant viewing of the actual reading displayed. In the section below it is described how to set up this feature:

- 1) On the [Test Set] → [Tolerance Limit] menu item the  key has to be pressed to activate the limit set screen.
- 2) The  key, the  and  key are to be used to change the bottom limit and the upper limit value to the desired values.
- 3) The  key has to be pressed to confirm the change and to return to the previous screen, or the  key has to be pressed to cancel the change.


If the measurement range is exceeded, the user will be reminded to re-set. If the bottom limit is larger than the upper limit, the values will be exchanged automatically.

4.9 Changing resolution

The instrument has got a selectable display resolution, which is 0.1 and 0.01mm.

On the [Test Set] → [Resolution] menu item the  key has to be pressed to switch between "high" and "low".

4.10 Unit scale

On the [Test Set] → [Unit] menu item the  key has to be pressed to switch back and forth between imperial and metric units.


4.11 Memory management



4.11.1 Storing a reading


There are 20 files (F00-F19) which can be used to store the measurement values inside the instrument.

At most 99 records can be stored in each file.




The following steps outline how to do this:


- 1) The  key has to be pressed to activate the [File Name] item on the main measurement screen.


- 2) The  and  key are to be used to select the desired file to save the data.

- 3) After a new measurement reading appears, the  key has to be pressed to save the measurement value to the current file. If the [Auto Save] function is activated, the measurement value will be automatically saved to the current file after a new measurement operation.

4.11.2 Viewing a stored reading





The  key has to be pressed multiple times until the [Record No] area on the measurement screen is highlighted. The  and  key are to be used to change the record number. The stored values, according to the record number from the memory, will be automatically read. They are displayed on the "Thickness reading" area of the screen simultaneously.

If the displayed record data shall be deleted from the memory, the  key has to be pressed.

The other way to view the stored record is by menu operations. On the [Memory Manager] → [View Mem Data] menu the  key has to be pressed to activate the memory viewing screen.

F00	05	5%
F01	00	0%
F02	00	0%
F03	00	0%
F04	00	0%
F05	00	0%
F06	00	0%
↓ F07	00	0%




At most eight files, including the file name, the record counts and the ratio used of the file can be showed on one screen.

Use the /  key to scroll up/down. Press  to exit browsing. Press  to see details of

Instruction Manual TU_US

that file.


F00	05	5%
F01	00	0%
F02	00	0%
F03	00	0%
F04	00	0%
F05	00	0%
F06	00	0%
↓ F07	00	0%

The  and  key are to be used to move the cursor to the line which you want to see details. The  key has to be pressed to see the details of that file.


4.00	5.01	6.01
7.00	8.01	

This screen displays the total five record data in the file F00.

4.11.3 Clearing selected files

The **【Memory Management】** menu screen has to be entered and the **【Delete by File】** menu item has to be highlighted. Then the  key has to be pressed. This function allows the user to delete the selected data files previously saved in memory.

4.11.4 Clearing all the files


The **【Memory Management】** menu screen has to be entered and the **【Delete all Data】** menu item has to be highlighted. Then the  key has to be pressed. With this operation all the measurement data stored in the memory will be deleted after confirmation.

4.12 Data printing

Before printing, one connection plug of the print cable (optional parts) has to be inserted into the socket on the up-left of the main body and the other plug into the communication socket of the mini-printer.


4.12.1 Print current file

The **【Print function】** menu screen has to be entered and the **【Print current】** menu item has to be highlighted.

Then the  key has to be pressed. This operation will send all data of the current file to the mini printer via RS-232 port and print them out.


4.12.2 Print selected file

The **【Print function】** menu screen has to be entered and the **【Print Memory】** menu item has to be highlighted.


Then the  key has to be pressed. After specifying the start file name and the end file name, the instrument will send all the data in the files specified to print out.

4.12.3

The **【Print function】** menu screen has to be entered and the **【Print all Mem】** menu item has to be highlighted.

Then the  key has to be pressed. This operation will send all the memory data to the mini printer to print them out.




4.13 System Set



The  key has to be pressed on the **【System set】** menu item and enter this submenu from the main menu.

1) When **【Auto save】** is set to <On>, the measured data are automatically stored to the current file.

2) When **【Key sound】** is set to <On>, the buzzer will make a short hoot every time if any key is pressed.

3) When **【Warn sound】** is set to <On>, if the measured value exceeds the limit, the buzzer will make a long hoot.


4) LCD Brightness Set: The  key has to be pressed on the **【System set】** → **【LCD Brightness】** menu item to enter the LCD Brightness screen.  has to be pressed to enhance, and  to weaken the brightness.

The  key has to be pressed to confirm the modification, or the  key has to be pressed to cancel it

4.14 System information


This System information function will display the information about the main body and the firm ware. The version will change with the firmware.


4.15 EL Backlight

With the background light, it is convenient to work in even dark condition. The  key has to be pressed to switch on or off the background light any moment it is needed after having powered on the instrument.

As the EL light will consume much power it only has to be turned on if necessary.


4.16 Battery information

Two AA size alkaline batteries are needed as power source. After several hours' usage of the preset batteries, the battery symbol on the screen will be shown as .

If battery capacity runs out, the battery symbol  will be shown and it will begin to flash. In this case, the batteries should be replaced.

If the instrument isn't used for a longer period, the batteries have to be removed.

Instruction Manual TU_US




- Procedure:
- 1 Power Off the instrument
 - 2 Take off the cover of the battery and take out the two batteries
 - 3 Insert the new batteries into the instrument
 - 4 Replug the battery cover
 - 5 Power on the instrument to check.

4.17 Auto Power off

The instrument features an "auto power off" function designed to conserve battery life. If it is not in use for 5 minutes or more, it will turn itself off. If the voltage of the battery is too low this function will also work.


4.18 System reset


The  key has to be pressed while powering on the instrument: factory defaults will be restored. All the memory data will be cleared during system reset. The only time this might be helpful is if the parameter in the instrument was somehow corrupted.

4.19 Connection to PC



This instrument is equipped with a RS-232serial port. Using the accessory cable, the instrument has got the ability to connect to a PC or an external storage device. Measurement data stored in the memory can be transferred to the PC through the RS-232 port. For detailed information of the communication software and its usage, refer to the software manual.

5. Menu operation


Both, presetting system parameters and the additional function are verified by menu operation. On the measurement screen, the  key has to be pressed to get into the main menu.




5.1 Enter the main menu

To enter the main menu, the key  has to be pressed to activate the menu items tab while being on the measurement screen. To turn back to the previous screen, the key  has to be pressed again.




5.2 Enter the Sub menu

The  key has to be pressed to enter the submenu screen while the submenu item is selected.


5.3 Change the parameter

The  key has to be pressed to change the value of a parameter while the item is selected on the parameter set screen.


5.4 Numeric digit input

The  key has to be pressed multiple times to tab to the numeric digit to be changed; the numeric values on the display can be decreased/ increased with the  and  key until the desired value is matched.

5.5 Save and exit

The  key has to be pressed to confirm the modification and to return back to the previous screen.

5.6 Cancel and exit

The  key has to be pressed to cancel the change and return back to the previous screen.

6. Servicing

Instruction Manual TU_US

If there should appear some abnormal phenomena to the instrument, please do not dismantle or adjust any fixed assembly parts on your own. Instead of this, the present warranty card has to be filled out and the instrument has to be sent to us. The warranty service can be carried on.

7. Transport and Storage

The instrument has to be kept away from vibration, strong magnetic fields, corrosive medium, dampness or dust. Storage in ordinary temperature.

Appendix A Sound velocities

Material	Sound Velocity	
	In/us	m/s
Aluminum	0.250	6340-6400
Steel, common	0.233	5920
Steel, stainless	0.226	5740
Brass	0.173	4399
Copper	0.186	4720
Iron	0.233	5930
Cast Iron	0.173-0.229	4400—5820
Lead	0.094	2400
Nylon	0.105	2680
Silver	0.142	3607
Gold	0.128	3251
Zinc	0.164	4170
Titanium	0.236	5990
Tin	0.117	2960
Epoxy resin	0.100	2540
Ice	0.157	3988
Nickel	0.222	5639
Plexiglass	0.106	2692
Polystyrene	0.092	2337
Porcelain	0.230	5842
PVC	0.094	2388
Quartz glass	0.222	5639
Rubber, vulcanized	0.091	2311
Teflon	0.056	1422
Water	0.058	1473

Appendix B Application Notes

Measuring pipe and tubing

When a piece of pipe is measured to determine the thickness of the pipe wall, the orientation of the transducer is of importance. If the diameter of the pipe is larger than approximately 4 inches, measurement should be performed with the transducer orientated in the way that the gap in the surface of the sensor is perpendicular (at right angle) to the long axis of the pipe.

For smaller pipe diameters, two measurements should be performed, one with the surface gap of the sensor perpendicular, another with the gap parallel to the long axis of the pipe. The smaller one of the displayed values should be taken as the thickness of that point.



Perpendicular Parallel

Measuring hot surfaces

The sound velocity through a substance is dependent on its temperature. As materials heat up, the velocity of sound through them decreases. In most applications with surface temperatures of less than 100°C, no special procedures must be observed. At temperatures above that point, the change in sound velocity of the material being measured starts having a noticeable effect upon ultrasonic measurement. At such elevated temperatures it is recommended to first performing a calibration on a sample piece of known thickness, which is at or near the temperature of the material being measured. This will allow the instrument to correctly calculate the sound velocity through the hot material.

When performing measurements on hot surfaces, it may also be necessary to use a specially constructed high-temperature transducer. These transducers are built of materials which can withstand high temperatures.

It is also recommended that the sensor has to be left in contact with the surface for a short time in order to acquire a stable measurement. While the transducer is in contact with the hot surface, it will be heated up and with thermal expansion and other effects, the accuracy of measurement may adversely be affected.

Measuring laminated materials

Laminated materials are unique because of their density (and therefore sound velocity) may considerably vary from one piece to another. Some laminated materials may even exhibit noticeable changes in sound velocity across a single surface. The only way to a reliable measurement is to perform a calibration on a sample piece of known thickness. Ideally, this sample material should be a part of the same piece being measured, or at least from the same lamination batch. The effects of variation of sound velocity will be minimized by calibrating each test piece individually.

An additional important consideration is, that any included air gaps or air pockets will cause an early reflection of the ultrasound beam. This will be noticed as a sudden decrease in thickness in an otherwise regular surface. While this may impede accurate measurement of the total material thickness, it does positively indicate any air gaps in the laminate.

Suitability of materials

Ultrasonic thickness measurement relies on passing a sound wave through the material being measured. Not all

Instruction Manual TU_US

materials are suited to transmitting sound. Ultrasonic thickness measurement is practically found in a wide variety of materials including metals, plastic and glass. Materials which are difficult include some cast materials, concrete, wood , fibreglass and some rubber.

Coupling medium

Every ultrasonic application requires some medium to couple the sound from the transducer to the tested material. Typically, a high viscosity liquid is used as the medium. The sound used in ultrasonic thickness measurement doesn't travel through air efficiently.

A wide variety of coupling mediums may be used. Propylene glycol is suitable for mostly all applications. In difficult applications, where a maximum transfer of sound energy is required, glycerine is recommended. However, on some metals glycerine may promote corrosion by means of water absorption, which is undesirable.

Other suitable coupling medium for measurements at normal temperatures may include water, various oils and greases, gels and silicone fluids. Measurements at elevated temperatures will require specially formulated high temperature coupling medium.

Inherent in ultrasonic thickness measurement is the possibility that the instrument will use the second rather than the first echo from the back surface of the material being measured while being in standard pulse-echo mode. This may result in a thickness reading that is TWICE what it should be.

The responsibility of a proper use of the instrument and the recognition of these types of phenomenon solely rest with the user of the instrument.

7. Declaration of conformity



SAUTER GmbH
 D-72458 Albstadt
 E-Mail: info@sauter.eu
 Tel: 0049-[0]7431- 938-666
 Fax: 0049-[0]7431-938-282
 Internet: www.sauter.eu

Konformitätserklärung


Declaration of conformity for apparatus with CE mark
 Konformitätserklärung für Geräte mit CE-Zeichen
 Déclaration de conformité pour appareils portant la marque CE
 Declaración de conformidad para aparatos con marca CE
 Dichiarazione di conformità per apparecchi contrassegnati con la marcatura CE

English We hereby declare that the product to which this declaration refers conforms with the following standards.
Deutsch Wir erklären hiermit, dass das Produkt, auf das sich diese Erklärung bezieht, mit den nachstehenden Normen übereinstimmt.
Français Nous déclarons avec cela responsabilité que le produit, auquel se rapporte la présente déclaration, est conforme aux normes citées ci-après.
Español Manifestamos en la presente que el producto al que se refiere esta declaración está de acuerdo con las normas siguientes
Italiano Dichiariamo con ciò che il prodotto al quale la presente dichiarazione si riferisce è conforme alle norme di seguito citate.

Thickness Gauge: SAUTER TU series SAUTER TN series

Mark applied	EU Directives	Standards
CE	96/37 EC 2006/95 EC 2004/108 EC	EN 50081-2 EN 50081-2

Date: 07.04.2009

Signature: 
SAUTER GmbH
Management

SAUTER GmbH, Schumannstrasse 33, D-72458 Albstadt, Tel: +49 (0) 7431 938 666, Fax: +49 (0) 7431 938 282