
Instruction Manual THP



Modell: THP

Thank you for buying a SAUTER horizontal manual Test Stand. We hope you are pleased with your high quality test stand with high repeatability and its big functional range. If you have any queries, wishes or helpful suggestions, do not hesitate to call our service number.

1. Included in delivery

- SAUTER THP (with *Fast-Move*)

2. Warning

Intended use

The instrument you have acquired serves to determine the measuring value of the material to be measured. It is intended to be used as a "non-automatic" instrument, i.e. the material to be measured is manually and carefully attached at the instrument. The measuring value can be read off after a stable measuring value has been obtained.

Be careful about the limit load of test stand and force gauge. Do not go over the maximum force.

3. Technical Specifications

Capacity: up to 500 Newton

Net weight: 8,4 kg

Various possibilities for fixture mountings

Height of the carriage travels above base plate: 15 mm

Closest starting point of the carriage right from the instrument: 115 mm

Furthest ending point of the carriage: 258 mm

Maximum Travel (with one stroke): **64 mm by *Fast-Move***

Length: 450 mm / height : 97 mm / width : 170 mm