


规格	A(mm)	B(mm)	C(mm)	D(mm)	E(mm)	F(mm)
1.0x1.0	1012	1012	896	896	500	500
1.0x1.2	1012	1212	896	1096	500	700
1.2x1.2	1212	1212	1096	1096	700	700
1.2x1.5	1212	1512	1096	1396	700	1000
1.5x1.5	1512	1512	1396	1396	1000	1000
1.2x2.0	1212	2012	1096	1896	700	1500
1.25x1.5	1262	1512	1146	1396	750	1000

技术要求:

1. 材质: 外框为4mm 碳钢板; 三角加强板为6mm 碳钢板;
2. 整体焊接成型, 清除焊渣, 表面喷漆处理, 颜色为Pantone Cool Gray 9 C;
3. 内框焊接后变形度要小, 与地磅组装后间隙比较均匀, 不可接触地磅台面;
4. 焊螺母的地方标配8个螺母和8个30mm内六角锥端紧定螺丝;
5. φ30出线孔和地磅出线孔位置对应。

LENGTH	TOLERANCE	REV	DESCRIPTION	DATE	DWG TITLE:
0~18mm	±0.10mm				TF地磅护框
18~30mm	±0.15mm				
30~50mm	±0.20mm				
50~80mm	±0.30mm				
80~120mm	±0.40mm				
120~180mm	±0.50mm	DRAWN 田耀坤 2009/09/11			DWG NO: STYT03-02
180~250mm	±0.60mm	DESIGN			MATERIAL: 碳钢
250mm以上	±0.80mm	APP.			FINISH: 喷漆
					UNIT: mm
					SCALE: 1/12
					PAGE: 1/1
					PROJECTION:


惠而邦电子衡器(昆山)有限公司
 TSCALE Electronics Mfg.(Kushan) Co., Ltd.