

Instruction Manual

TA FN-car

DIGITAL COATING THICKNESS GAUGE FOR AUTOMOTIVE TRADE



Model: TA 1000-1FN-car

Digital coating thickness gauge, specially designed for the automotive industry and trade, as well as for paint shops.

1. Instrument's details



2. Basic operation

- Turn on the instrument by the TRIGGER
- Proceed to measure your sample or for 0-calibration
- Press the SENSOR on the base plate
- Press the ZERO key

3. Units

- Press MILS / μM to change the unit of reading


4. Backlight

- Press  to activate the display backlight

5. Battery

Battery: 9V block battery

Battery life: 9 hours continuously, including backlight

Low battery indication: If the symbol  appears, the battery voltage drops below the operating level and batteries are to be changed.

6. Conditions / technical details

Environmental conditions: Temperature: 0°C bis 50°C
 (32°F bis 122°F)
 Humidity: < 75% R.H.

Auto Power Off: 30 seconds

Dimensions: L x W x H: 148mm x 105mm x 42mm

Weight: ca. 157g (inclusive battery)

Detectable base material: ferrous metal (iron, steel) and non ferrous metal (copper, aluminium, zinc, bronze, brass etc.)

7. CE Declaration of Conformity




SAUTER GmbH
 D-72468 Albstadt
 E-Mail: info@sauter.eu
 Tel: 0049 (0)7431-938-666
 Fax: 0049 (0)7431-938-252
 Internet: www.sauter.eu

Konformitätserklärung


Declaration of conformity for apparatus with CE mark
 Konformitätserklärung für Geräte mit CE-Zeichen
 Déclaration de conformité pour appareils portant la marque CE
 Declaración de conformidad para aparatos con marca CE
 Dichiarazione di conformità per apparecchi contrassegnati con la marcatura CE

English We hereby declare that the product to which this declaration refers conforms with the following standards.
Deutsch Wir erklären hiermit, dass das Produkt, auf das sich diese Erklärung bezieht, mit den nachstehenden Normen übereinstimmt.
Français Nous déclarons avec cette responsabilité que le produit, auquel se rapporte la présente déclaration, est conforme aux normes citées ci-après.
Español Manifestamos en la presente que el producto al que se refiere esta declaración está de acuerdo con las normas siguientes.
Italiano Dichiariamo con ciò che il prodotto al quale la presente dichiarazione si riferisce è conforme alle norme di seguito citate.

Coating Thickness Gauge: SAUTER TA

Mark applied	EU Directive	Standards
	95/33/EEC/EMC	EN 61326 : 1997+A1 : 1998+A2 : 2001 EN 55022 EN 61000-4-2 : 1-3

Date: 07.01.2010

Signature: 
 SAUTER GmbH
 Management

SAUTER GmbH, Schumannstrasse 33, D-72468 Albstadt, Tel: +49 (0) 7431 938 666, Fax: +49 (0) 7431 938 252

8. Included instrument, accessories

- TA coating thickness gauge
- Base plates (for F and N)
- Instruction manual
- Soft carrying pocket